

DOC6406-02

Orient Prism Face as shown for direct pointing before tightening the connection.



Includes strong metal "U" Bracket to add strength to the pole connections, placed between any section or point. To prevent the adhesive breakdown on the prism contact points, the U Bracket must be used at all times.